

S197 Non-Adjustable Lower Control Arms

Installation Instructions

1. Lift rear of Mustang
2. Put jack stands under rear axle
3. Remove both rear wheels
4. Unhook the right brake cable where it attaches on the caliper, using a small, regular screwdriver
5. Slide the brake cable out of the control arm
6. Remove both control arm bolts (18mm) to remove the right control arm
7. Apply lubricant to the face of the polyurethane
8. With the wide end to the rear, and the grease zerk facing down, reinstall the bolts and tighten to 129 lb-ft
9. Use a pry-bar to rotate the brake lever in order to re-install the right brake cable
10. Use a heavy duty zip tie to secure brake cable to control arm
11. Unhook the left brake cable where it attaches on the caliper, using a small, regular screwdriver
12. Slide the brake cable out of the control arm
13. Remove both control arm bolts (18mm) to Remove the left control arm
14. Apply lubricant to the face of the polyurethane
15. With the wide end to the rear, reinstall the bolts and tighten to 129 lb-ft
16. Use a pry-bar to rotate the brake lever in order to re-install the left brake cable
17. Use a heavy duty zip tie to secure brake cable to control arm
18. *(If equipped with grease zerks)* Using a grease gun, apply one full pump of silicone-based grease made for polyurethane to each zerk. Add one more pump of grease after three hundred miles and every four thousand miles thereafter. Overfilling could lead to premature poly wear.
19. Double check everything, re-install wheels, lower vehicle, and enjoy improved performance!



This aftermarket performance accessory was not designed by your vehicle's manufacturer. Purchaser assumes all risk of any damage caused to the vehicle or person during installation or use of this product.