

SR Performance Front Sway Bar End Links

Installation Instructions

1. Lift front of Mustang
2. Secure with jack stands
3. Remove left factory link
4. Adjust both new sway bar end links so they are the same length as the factory piece you just removed. Make sure the rod ends have an equal amount of threads showing. Leave the jam nuts loose.
5. Install either of the new links on the left side (bolt, washer, rod end, aluminum bushing) and tighten bolts (12mm) 75 lb-ft
6. Remove right factory link
7. Install new link on the right side (bolt, washer, rod end, aluminum bushing) and tighten bolts (12mm) 75 lb-ft
8. Lower vehicle and ensure it has settled back to ride height by rolling or pushing on vehicle
9. *Adjust by simply turning new end link bars
10. Apply blue Loctite and tighten jam nuts.
11. Double check everything and enjoy improved performance!

** No load = Neutral position (factory setting)*

** Slight Load = Bar is adjusted slightly past the neutral position for daily driver use*

** Loaded = Bar is adjusted well past the neutral position for increased handling*



This aftermarket performance accessory was not designed by your vehicle's manufacturer. Purchaser assumes all risk of any damage caused to the vehicle or person during installation or use of this product.