



CLASSIC QUARTER WINDOW SCOOP

(PRODUCT FITMENT, YEAR RANGE/MODEL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) RH Quarter Window Scoop
- (1) LH Quarter Window Scoop
- (1) RH Insert
- (1) LH Insert
- (1) Dual Lock Tape Kit
- (4) Alcohol Pads
- (2) Adhesion Promoters

TOOLS REQUIRED

- Glass Cleaner
- Microfiber Towel

STEP 1



Begin by thoroughly cleaning the quarter window glass with glass cleaner. Using one of the supplied alcohol pads, clean the areas of the window glass where the tape will make contact, and the tape ledges on the quarter window scoop. Once the alcohol has dried, treat those same areas with the supplied Adhesion Promoter and let dry. Make sure to also clean the recessed opening on the front of the scoop, where the insert will adhere, with the alcohol pad. You do not need to use Adhesion Promoter for the insert.

STEP 2



Once the alcohol on the tape ledges has dried, apply the supplied tape as shown above.



STEP 3

Remove the tape backing from the insert and install in the recessed opening on the front of the scoop. Make sure the top of the insert sits flush against the top of the opening. If the bottom of the insert sticks out past the body of the scoop, it may prevent it from sitting flush on the window.



STEP 4

Test fit the scoop before removing the tape backing so you have a clear understanding of how it sits within the quarter window molding. The top edge of the scoop should follow the bottom edge of the style line/groove in the quarter window molding, highlight in GREEN. The front edge should be flush with the end of the window molding and parallel with front edge of the glass. Please reference the pictures in Step 5 & 6 for front edge alignment.

STEP 5



Remove the tape backing. Align the bottom edge with the edge of the quarter window molding. The front edge of the scoop should be parallel with the edge of the window glass. The top edge of the scoop should follow the style line/groove in the quarter window molding.

STEP 6



Once the quarter window scoop has been properly aligned, press down firmly on all taped areas to fully seat the adhesive. Wait at least 24hrs before attempting to separate the scoop from the Dual Lock tape. Repeat these steps for the opposite side.