



## 2011-2014 Mustang 5.0 Sound Tube Delete Kit

Installation Instructions:

### STEP 1: Sound Tube Removal

1. Squeeze open hose clamp (REF 1, RED ARROW) and disconnect sound tube from intake.
2. Pull rubber retainer off metal tab attached to shock tower, under strut brace (REF 1, BLUE ARROW).
3. Remove fastener (PINK ARROW).
4. Pull sound tube out from firewall (REF 1, GREEN ARROW).
5. Remove sound tube from engine bay (REF 1 YELLOW LINE).

### STEP 2: Delete Kit installation

1. Install tube cap over intake nipple and secure with supplied worm clamp (REF 2, YELLOW ARROW).
2. Install firewall plug (REF 2, YELLOW ARROW). Be sure to fully seat the plug by firmly pushing all around the crease on the front of the plug. Failure to do so will result in the plug falling out.

THAT'S IT! ENJOY!

REF 1



REF 2



REF 3

