



## 11-14 Upper Control Arm

### Contents:

(1) - Upper control Arm

### Tools Needed:

- 18, 21, 24, 27mm Sockets
- 18, 21mm Wrench
- Ratchet/Impact Driver
- Pry Bar
- Jack
- Jack Stands



### **\*\*Important Notes:**

**Professional alignment is highly suggested after installation to prevent poor handling, and premature tire wear.**

**Step 1:**

Move the seats forward to access the rear seat bottom. Feel for the clips (1) on either side, push them to release the rear seat. Remove from the car.



**Step 2:**

Using a 24mm socket, remove the rear upper control arm bracket bolt.



**Step 3:**

From the underside of the vehicle, locate the upper control arm and upper control arm bracket. Using a 21mm socket, remove the upper control arm from the axle. Then using an 18mm socket, remove the (2) bracket bolts. Remove the assembly from the vehicle.



**Step 4:**

Remove the upper control arm from the bracket using a 27mm socket and a 21mm wrench.



**Step 5:**

Install the SR upper control arm in the bracket using the factory bolt.



**Step 6:**

Reinstall the SR upper control arm with the installed bracket. Torque all bolts to factory spec. Be sure to grease the bushing as needed.

