

15-16 GT350 Style Gille Extensions

REQUIRED Alcohol Wipes

Adhesion Promoter



Begin by test fitting the extensions. ****Note:** which extension goes on which side.



Clean the grille of dirt and debris using soap and water. Once thoroughly dry, wipe the highlighted locations down with the supplied alcohol wipes.



Remove the tape backing and apply the adhesion promoter. Allow the adhesion promoter to flash dry. Then position the grille extensions.



Apply firm even pressure to ensure proper adhesion to the factory grille.