

15-17 Bumper Splitters

REQUIRED Flat Screw Driver


7mm Socket and ratchet



Gain access to the back side of the fog/turn signal bumper bracket. Raise the front of the vehicle using a jack and support with jack stands. Turn the wheels so that you can remove the clips holding the fender liner to the bumper.



Fold back the fender liner and remove the screw circled above from the fog/turn signal bumper bracket. **Note: The bumper does not need to be removed.



Thoroughly clean the mounting surface using soap and water (dashed lines above). Once dry, clean the surfaces with the provided alcohol wipe. Ensure the surface is completely dry.



Before removing the tape test if the part so you can see how it fits the bumper. Apply slight pressure to the fog/turn signal bracket so that you can slide the bumper splitter between the bracket and the bumper.



Once comfortable with the way the part fits, remove the tape backing. Apply the supplied adhesion promoter to the tape and allow it to flash dry. Then install the splitter to the bumper. Slide the splitter between the bracket and the bumper. Then apply firm even pressure to the velcro to ensure proper adhesion. Then Reinstall the bracket screw and fender liner.



