

## **ROCKER WINGLET**

(2015-2020 MUSTANG GT, ECOBOOST, V6)

## **INSTALLATION INSTRUCTIONS**

## **CONTENTS**

- (1) LH Rocker Winglet
- (1) RH Rocker Winglet
- (6) Plastic Push Rivets

## **TOOLS REQUIRED**

1/4" Drill Bit & Drill T20 Torx Bit & Ratchet Flat Head Screw Driver





STEP 1

**FRONT PLACEMENT:** Locate the winglet by placing it against the front edge of the rocker. Space the winglet 1/4" off the rocker panel, 1/4" gap is recommended, but the winglet can be moved in or out as desired. Use a clamp to hold the winglet in place so you can step back and confirm its placement.



STEP 2

**FRONT PLACEMENT:** With an extra set of hands, clamp, or painters tape, hold and drill (3) 1/4" mounting holes in a staggered pattern. Please take caution when drilling, you only want to drill through the bottom surface of the chin spoiler. If you drill too far, you may drill through the top of the rocker panel. Secure the Winglet with the supplied push rivets.



STEP 1



**REAR PLACEMENT:** Remove the (2) T20 Torx screws and (1) push clip attaching the rocker guard to the rocker. Locate the winglet by placing it against the rear edge of the rocker. Space the winglet 1/4" off the rocker panel, 1/4" gap is recommended, but the winglet can be moved in or out as desired. Use a clamp to hold the winglet in place so you can step back and confirm its placement.



**REAR PLACEMENT:** With an extra set of hands, clamp, or painters tape, hold and carefully drill (3) 1/4" mounting holes in a staggered pattern. Please take caution when drilling, you only want to drill through the bottom surface of the chin spoiler. If you drill too far, you may drill through the top of the rocker panel. Secure the Winglet with the supplied push rivets.