

MP CONCEPTS

15-17 Gloss Black Decklid Overlay

REQUIRED Panel Removal Tool 1/4 Metric Socket Set
Flat Screw Driver



1 Using a panel removal tool, remove the caps covering the deck lid panel bolts. Then, remove the (4) 7mm screws.



3 Unplug the reverse camera. Then remove the panel from the vehicle.



2 Use the panel removal tool to gently separate the factory deck lid panel from the deck lid.



4 Remove the deck lid emblem by carefully removing the plastic weld from the back of the deck lid panel. Use an oversized drill bit and only remove enough material so that you can remove the emblem.



5 Wash the deck lid panel with soap and water. Allow the panel to dry. **Recommended: Wipe the panel down with isopropyl alcohol to ensure the cleanest surface possible.



6 Apply the supplied tape to MP Concepts overlay, ensure all edges are covered. Remove the tape backing and install the overlay. Apply firm even pressure to ensure proper adhesion.