

MP CONCEPTS

15-17 GT350 Style Fender Vent

1



Wash the fenders with soap and water. Allow the panel to dry.
**Recommended: Wipe the panel down with isopropyl alcohol to ensure the cleanest surface possible.

3



Test fit the insert again, ensure sure the end sit flush with the vent otherwise, the vent will not fit correctly on the car.

5



Install the 3M tape on the Fender vent as seen above. Before removing the tape backing, make yourself familiar with the way the vent fits on the vehicle.

2



Prepare the fender vent by first installing the Fender Vent insert. Test fit the insert on the vent. Remove the insert and apply the supplied 3M double sided tape.

4



Remove the tape backing from the insert, install the insert onto the vent.

6



Peel off the double sided tape backing and apply the vent to the vehicle. Apply firm even pressure to ensure proper adhesion.