

MP CONCEPTS

15-17 Quarter Window Scoop



Wash the quarter window with soap and water. Allow the window and surrounding area to dry. ****Recommended:** Wipe the panel down with isopropyl alcohol to ensure the cleanest surface possible.



Apply the supplied 3M tape to the scoop insert. Test fit the insert on the scoop to familiarize yourself with how it fits. The insert edges need to be flush with the scoop otherwise, the scoop will not fit correctly.



Remove the tape backing and install the insert onto the scoop.



Apply the supplied 3M tape to the scoop as seen above.



Test fit the scoop before removing the tape backing. Once you are comfortable with how the scoop fits, remove the tape backing. Apply firm even pressure to ensure proper adhesion.