

# MP CONCEPTS

## Installation Instructions for MUSTANG Lettering

### Step 1:

Starting by cleaning the deck lid panel. Ensuring that the panel is free of any wax or grease. Apply a piece of masking tape across the center of the panel.



### Step 2:

Using the tape as a reference point, center the "T" and space the letter evenly from the center out. All of the letter are the same width. For reference the letters are spaced at 1/2" intervals.



### Step 3:

Once the letters are evenly spaced, remove one letter at a time. Apply the supplied 3M tape.



### Step 4:

Remove the tape backing and install the letter to the deck lid panel. Apply firm even pressure to ensure proper adhesion.

