



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **2005-2009 MUSTANG STAINLESS UPPER DOOR PANEL INSERTS PART#271003 patent pending**



**PLEASE NOTE:** If you plan on installing our matching arm rest panels in the future for best results we recommend that they should be installed first. However these door inserts can be installed without our matching arm rests.

#### **PARTS INCLUDED:**

- 2-Brushed Stainless Door Panel Inserts
- 2-Packs Adhesive Promoter
- 2-30" of 1/4" Chrome Molding
- 2-Tubes of Adhesive Promoter
- 1-Test Kit

**Your new covers come to you with a protective liner.  
Do not remove liner until installation is complete.**

1. Your new door panel insert is designed to permanently stick to your door panel via 3M Super Attachment Tape and is very reliable however if this area has been treated with armor all or any silicon based treatments this installation will not work unless special chemicals and procedures are followed. Please refer to the SPECIAL INSTRUCTIONS ATTACHED.
2. Scrub the top of the door pull area with household rubbing alcohol to prepare the surface. Once this is done use the adhesive promoter (provided) to wipe the entire area to be covered with your new door panel. **NOTE:** Be careful not to apply any excess adhesive promoter anywhere outside of the area where

you will be mounting your new kit as this will leave a mark on your door panel. Allow a few seconds to dry. **You have been provided with attachment tape test strips. Use one of these to test the tack. If it seems to stick well then you can proceed with your installation. If you can not get the test tape to stick please refer back to the special preparation instruction sheet and repeat those procedures.**

3. Before permanently attaching place the upper insert in position to check the fit and to get acquainted with just how it installs. You will notice a small notch area to be inserted into the arm rest if installed correctly it should sit nice and tight to the arm rest panel leaving no gaps. Once you are clear about how it sits peel the red release liner and press the panel firmly in place.
4. You have been provided with a length of chrome trim and a tube applicator of adhesive promoter. Squeeze the tube to break the fluid capsule and apply a thin swipe directly to the outer edge of the DOOR PANEL AROUND the panel insert you just installed.
5. Peel a small length of the red release liner from one end of the chrome trim and firmly press it directly to the door panel peeling the liner as you go and making sure that the trim rests tightly against the edge of the panel insert. Work your way to the end and cut away any excess trim.
6. Repeat process for opposite side.



**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact  
AMERICAN CAR CRAFT  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**