



AMERICAN CAR CRAFT INSTRUCTIONS

Tag Frame "5.0" Lettering Carbon Fiber Colors PART #272028



PARTS INCLUDED:

- 1-Chrome/Stainless/Carbon Fiber Tag Frame
- 2-M6-1.0x20mm Zinc Plated Course Head
- 2-124NC 10mmChrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.