

Step 1:

From below, reach behind the bumper cover and depress the clip on the front of the light.



Step 2:

Depress the wiring harness plug to remove the light from the vehicle.



Step 3:

(A) Remove the bulb and socket from the factory light.(B) Plug the Axial light into the factory light socket(C) Twist the light socket into the light.



Step 4:

Reinstall the LED marker light in reverse order.

