



Wash the quarter window with soap and water. Allow the window and surrounding area to dry. **Recommended: Wipe the window down with isopropyl alcohol to ensure the cleanest surface possible.



Apply the supplied 3M tape to the scoop as seen above. Test fit the insert on the scoop to familiarize yourself with how it fits.



Remove the tape backing and install the insert onto the scoop.



Apply firm even pressure to all taped surfaces to ensure proper adhesion.