

MP CONCEPTS

Installation Instructions for 2015 - 2018 Rear Side Marker Lights

Step 1:

From below, reach behind the bumper cover and depress the clip on the front of the light.



Step 2:

Depress the wiring harness plug to remove the light from the vehicle.



Step 3:

- (A) Remove the bulb and socket from the factory light.
- (B) Plug the MP Concepts light into the factory light socket.
- **Note: The connection is very tight. If the board doesn't press right in, use the corner of the board to press the retaining clip out of the way.
- (C) Twist the light socket into the light.



Step 4:

Reinstall the LED marker light in reverse order.

