

15-17 Paddle Shifter Extensions

REQUIRED Alcohol Wipes

Adhesion Promoter



1
Clean the paddle extension with the supplied alcohol wipe allow time to flash dry Then peel back the adhesive backing and apply the double sided tape to paddle extension.



2
Clean the mounting surfaces with the supplied alcohol, allow time to flash dry.



3
Peel back the adhesive backing. Line the extension up with the factory paddle shifter.



4
Apply firm pressure to the paddle and paddle extension to ensure proper adhesion.