

# Grille Induction Kit (15-17 GT)

1. Remove the bumper cover to gain access to the installation location.
2. Place the Grille Induction Kit in the corner of the grille openings. They are held in with pressure. The factory rubber air dams will hold them in place.
3. Carefully re-install the bumper cover. You may need to slightly adjust the inlets as you install the bumper cover.

