



Begin by thoroughly cleaning the bumper with soap and water. Allow time for the bumper to dry. Using the supplied alcohol pad, clean under the light surface on both sides.



Before installing the bumper winglet, test fit the winglet to familiarize yourself with where it fits best.



Apply the supplied 3M tape to the back side of the winglet. Test fit the part again before removing the tape backing.



Remove the tape backing and install the winglet to the under side of the light. Apply firm even pressure to the taped surface to ensure proper adhesion.