



2018+ Quarter Window Louvers

TOOLS REQUIRED: Towel / Cloth
Glass Cleaner

CONTENTS: 2 - Louvers
4 - Inserts
1 - Tape Kit
2 - Alcohol Wipes
2 - Adhesion Promoter

1



Using the supplied alcohol wipes, wipe the tape ledges on the louver and window, allow time to dry. Then use the promoter, allow time to dry.

2



Apply the supplied tape as seen above.

3



Apply the supplied tape to the (4) inserts. The inserts will be labeled L-U for Left Upper, L-L for Left Lower, R-U for Right Upper, and R-L for Right Lower.

4a



Install the inserts to the louvers by removing the tape backing and applying the inserts upward first then the bottom.

4b



Apply firm pressure to the inserts making sure inserts adhere to the louver.

5



Fit the part before removing the tape backing. The louver should be aligned with the back corner and top edge first. Remove the tape backing, and apply firm pressure over all the tape surfaces.