

Installation Instructions for Carbon Fiber Accessories (15-17All)

Bumper Splitters



Step 1:

Before removing the installed tape backing place the splitter on the bumper and feel for best fitment. You will notice that the splitter contacts the paint best in one location. The small splitter mounts below the larger splitter.



Step 2:

Thoroughly clean the vehicle's paint/plastic ensuring it is wax and grease free. Clean the surface with the provided cleaner. Once dry, peel the tape backing off and apply the adhesion primer. Allow the primer to flash dry and then install. Apply firm even pressure to tape surfaces to ensure proper adhesion.

Mirror Covers



Step 1:

Clean the back side of the mirror cover with isopropyl alcohol. Once dry, apply the supplied tape as shown.



Step 2:

Thoroughly clean the vehicle's mirror ensuring it is dirt, wax and grease free. Once dry, peel the tape backing off and apply the adhesion primer. Allow the primer to flash dry and then install. Apply firm even pressure to tape surfaces to ensure proper adhesion.

Tail Light Trim



Step 1:

Clean the back side of the Tail Light Trim with isopropyl alcohol. Once dry, apply the supplied tape as shown.



Step 2:

Thoroughly clean the tail light ensuring it is dirt, wax and grease free. Once dry, peel the tape backing off and apply the adhesion primer. Allow the primer to flash dry and then install. Apply firm even pressure to tape surfaces to ensure proper adhesion.