

(15-19) MUSTANG Decklid Panel

CONTENTS: (1) Replacement Decklid Panel

REQUIRED: Panel Removal Tool 5.5mm, 7mm 1/4" Sockets
 Flat Head Screw Driver 1/4" Ratchet



1 Using a panel removal tool, gently remove the caps covering the deck lid panel screws. Remove the (4) 7mm screws.



2 Using a panel removal tool, carefully separate the factory deck lid panel from the deck lid. It is clipped into the decklid along the top edge. **Note: Do Not pry against the paint, decklid dents easily.



3 Unplug the reverse camera and remove the panel from the vehicle. Remove the (2) 5.5mm screws securing the camera to the panel. **Note the orientation of the camera. If reinstalled backwards the camera will be inverted on the display. Reinstall the factory camera onto the MMD panel reusing the factory screws.



4 Remove the factory (4) push clips across the top of the decklid panel. Transfer these clips onto the MMD panel.



5 Remove the (4) factory screw clips across the bottom of the decklid panel. Transfer these clips onto the MMD panel.



6 Plug in the camera and reinstall the decklid panel using the factory screws. Finish the install by reinstalling the factory screw covers.