

MP CONCEPTS

Contents:

- (1) Rear Diffuser
- (2) Outer Diffuser Trim
- (4) Spacers

Tools Required:

- 7mm, 10mm Sockets
- Ratchet & Extensions
- Phillips Head Screw Driver
- Jack & Jack Stands
- Trim Panel Removal Tool

Step 1:

Jack the rear of the vehicle up, and support using jack stands. Locate, and remove the (2) push pins to access the outer diffuser trim screws using a trim panel removal tool.



Step 2:

Remove the (3) 7mm bolts holding the diffuser trim to the outer edge of the bumper.



Step 3:

Locate, and remove the (4) 7mm screws holding the center of the diffuser to the bumper support.



Rear Diffuser - Single Outlet 15-17 Mustang

Step 4:

Unplug the reverse light wiring harness, and using a trim panel removal tool remove the push clip holding the wiring harness to the light housing.



Step 5:

Using a trim panel removal tool, carefully pry the rear diffuser trim away from the rear bumper. Take your time, these can be tricky.



Step 6:

After the factory trim is removed, you will need to cut the factory diffuser free from the bumper. **Note: Use the dotted lines below as a reference.



Step 7:

Using a phillips head screw driver, remove the (4) screws holding the factory reverse light to the diffuser. Transfer the reverse light to the new MP Concepts diffuser.



Step 8:

Transfer the reflectors from the factory bumper to the new bumper. They are held on with a 10mm nut.



Step 9:

Transfer the screw clips from the factory diffuser trim panel to the new diffuser using a trim panel removal tool.



Step 10:

Connect the main diffuser to the (2) outer diffuser trim panels.



Step 11:

Reinstall the diffuser to the bumper in the reverse order.

