

# MP CONCEPTS

## Contents:

- (1) Rear Diffuser
- (4) Spacers

## Tools Required:

- 7mm, 10mm Sockets
- Ratchet & Extensions
- Phillips Head Screw Driver
- Jack & Jack Stands
- Trim Panel Removal Tool

### Step 1:

Jack the rear of the vehicle up, and support using jack stands. Locate, and remove the (2) push pins to access the outer diffuser trim screws using a trim panel removal tool.



### Step 2:

Remove the (3) 7mm bolts holding the diffuser trim to the outer edge of the bumper.



### Step 3:

Locate, and remove the (4) 7mm screws holding the center of the diffuser to the bumper support.



## Rear Diffuser - Dual Outlet 18+ Mustang

### Step 4:

Unplug the reverse light wiring harness, and using a trim panel removal tool remove the push clip holding the wiring harness to the light housing.



### Step 5:

Using a trim panel removal tool, carefully pry the rear diffuser trim away from the rear bumper. Take your time, these can be tricky.



**Step 6:**

Using a phillips head screw driver, remove the (4) screws holding the factory reverse light to the diffuser. Transfer the reverse light to the new MP Concepts diffuser.



**Step 7:**

Transfer the reflectors from the factory bumper to the new bumper. They are held on with a 10mm nut.



**Step 8:**

Transfer the screw clips from the factory diffuser trim panel to the new diffuser using a trim panel removal tool.



**Step 9:**

Reinstall the diffuser to the bumper in the reverse order.

