

MP CONCEPTS

18+ Hood Vents

Contents:
(2) Hood Vents
(8) M5 Studs
(8) Nuts

Tools Required:
8mm, 9mm, 10mm Sockets
Ratchet
Trim Panel Removal Tool
Drill & 1/4" Drill Bit

Step 1:

Using a trim panel removal tool, remove the hood liner push pins and remove the liner to gain access to the factory hood vent mounting nuts.



Step 2a:

Remove the (4) 9mm nuts holding the factory vent in place.



Step 2b:

Carefully pull up on the back of the hood vent while gently pushing the front to release the factory clip securing the hood vent to the hood. Remove hood vent.



Step 3:

Using a 10mm socket and ratchet, install the (4) studs to the MP Concepts hood vent.



Step 4:

Using a 1/4" drill bit & drill, carefully drill through the four factory hole locations.



Step 5:

Carefully insert the MP Concept hood vent through the hood and secure with the (4) supplied nuts. **Note, do not overtighten.



Step 6:

Reinstall the hood liner. Installation is now complete.

