

# MP CONCEPTS

## Installation Instructions for 2018+ Smoked LED Sidemarkers

### Step 1:

From below, reach behind the bumper cover and depress the clip on the front of the light.



### Step 2:

Depress the wiring harness plug to remove the light from the vehicle.



### Step 3:

- (A) Remove the bulb and socket from the factory light.
- (B) Plug the MP Concepts light into the factory light socket.
- \*\*Note: The connection is very tight. If the board doesn't press right in, use the corner of the board to press the retaining clip out of the way.
- (C) Twist the light socket into the light.



### Step 4:

Reinstall the LED marker light in reverse order.

