Carbon Fiber Key Fob Cover

(15-17 Mustang) (Non-Remote Start/Manual)



- (1) Front Key Fob Cover
- (1) Back Key Fob Cover

Tools Required:

Clean Towel
Cleaning Solution



Step 1Begin by cleaning your factory key fob of any dirt or debris.



Step 2Insert the back key fob cover onto the key fob.



Step 3Insert the front key fob cover onto the key fob.



Step 4Secure the front and rear key fob covers to the key fob by clicking them together. Installation is now complete.