



DECKLID PANEL

(2005-2009 MUSTANG ALL)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Decklid Panel

TOOLS REQUIRED

Detailer/Soap
Microfiber towel

STEP 1



Clean the rear section of the vehicle using automotive soap and water, dry thoroughly. Using the supplied alcohol prep pads, clean the rear decklid where the adhesive strips from decklid panel will be applied.

STEP 2



Peel the backing from the adhesive strips on the rear of the decklid panel.

STEP 3



Place the decklid panel over rear decklid using center pony emblem as a reference point. Make sure that decklid panel is centered and extends evenly to both sides of decklid. Also take care to ensure that corners meet top edge of decklid on both sides and follow contour of factory tail lights.

STEP 4



When the decklid panel is properly aligned, firmly press down on all taped areas to fully seat the adhesive.