

2011-2014 Mustang V6 Throttle Body Spacer Installation

1. Remove the factory or aftermarket cold air intake
2. Using an 8mm socket, remove the 4 bolts holding the throttle body to the intake manifold



3. Place the supplied gasket between the throttle body and the spacer.



4. Remove the hose highlighted in the picture below found to the left of the throttle body and replace it with the supplied hose in the kit.



5. Using the supplied longer hardware, reinstall the throttle body, throttle body spacer assembly.
6. Tighten all bolts to factory specification and reinstall the intake