



COLD AIR INTAKE

(2015-2017 MUSTANG ECOBOOST)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Intake Tube
- (1) Air Filter
- (2) Couplers
- (4) Clamps
- (1) PCV Grommet
- (1) PCV Adapter
- (1) Torx Bit

TOOLS REQUIRED

- Metric Socket Set & Ratchet
- Metric Allen Wrenches/Sockets
- Flat Head Screwdriver



STEP 1

Begin by removing the 10mm bolt that holds the air box to the fender, there is a rubber grommet that will be reused. Remove the Intake air sensor plug and wiring retaining clip. Remove the bypass valve tube and PCV hose. Loosen the clamps on the turbo and air box side of the intake tube. Remove Intake tube and Air box.



STEP 2

Install the filter adapter through the air box using three 1/4" button head screws and washers.



STEP 3



Remove the IAT sensor from the air box by turning it counter clockwise. Replace the factory O-ring with the supplied O-ring.

STEP 4



Secure the intake air sensor using the supplied large washer and allen head bolt. Install the silicone coupler, shown above, onto the end of the intake hose using the two large clamps.



STEP 5



Install the supplied grommet and PCV adapter. Then, install the silicone coupler reducer and secure with a large and small clamp.

STEP 6



Install the air box using the factory fender bolt and rubber grommet removed in Step 1. Then, install the air filter on to the filter adapter installed in Step 2. Remove the protective film from the air box window before installing with (6) 1/4" button head screws and washers. Install the small end of the inlet tube on the turbo inlet, then reconnect the PCV and bypass hose. Connect the large end of the intake tube to the air box. Reconnect the intake sensor and plug the wire harness clip into the air box to finish the installation.