

2005-2009 Emblem Cover



Before beginning, be sure to thoroughly clean the emblem and area around the emblem on the rear decklid. This will ensure the adhesive tape adheres properly.

1



Using the supplied alcohol prep pad, thoroughly wipe down the chrome plated area of the emblem where the cover will adhere.

3



Install the cover over the emblem as shown, making sure it is aligned properly. Once the cover is properly positioned, press down firmly around the edges to fully seat the adhesive tape.

Contents:

- (1) - Emblem Cover
- (1) - Alcohol Prep Pad

2



Peel the backing from the adhesive tape by using the supplied tab as shown.



MMD
MODULAR MUSCLE DESIGN