



Grille Installation Instructions

15-18 Dodge Challenger Upper & Lower Billet Grille (For all overlay style)

Hardware

4(6)—bolts 4(6)—toggle nuts

NOTE: Be Careful not to scratch the grills Surface.

- (1) Remove the factory plastic grille from your vehicle. Optional (for vehicles with black plastic cover under hood). Pop hood, remove the black plastic cover on top of factory grille (front panel) from vehicle, this will allow access to the rear of the grille shell.
- (2) Insert bolt from front of billet grille, then screw the toggle nut on the bolt, see picture 1#.
- (3) Place billet grille into opening factory grille shell, push the bolt, and have the toggle through the factory grille shell holes, adjust billet grille to be sure it is center and tight each bolt is ok, see picture 2#
- (4) Re-install factory grille.



(We are not responsible for any scratching so please take caution during the installation.)

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!