

Grille installation instructions

08-14 Dodge Challenger Main Phantom Billet Grille (overlay style)


Hardware

2—"U" bracket tabs 4—nuts 2—flat bracket 8—smaller washers

4— "U" Lock nuts 4—M4 screws 2—washers 4—"L" tabs

Above hardware we listed some maybe need not to be used, they are spare only. NOTE: **Be Careful not to scratch the grills Surface.**

- (1) Remove the factory plastic grille from your vehicle. Optional (for vehicles with black plastic cover under hood). Pop hood, remove the black plastic cover on top of factory grille (front panel) from vehicle, this will allow access to the rear of the grille shell.
- (2) Insert "U" nuts on the "U" bracket tabs, then install them with M4 screws on the billet grille, see below picture 1# on the billet grille.
- (3) Place billet grille into opening factory grille shell, at this time, the stud also go through factory grille shell see below picture 2#
- (4) Insert flat brackets and washers, adjust the billet grille to center, tight each nut is ok. See below picture 3#
- (5) Re-install factory grille.



(We are not responsible for any scratching so please take caution during the installation.)

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!