



Grille Installation Instructions 08-14 Dodge Challenger Main & Lower Billet Grille (overlay style)

Hardware

4 (3) —“U” bracket tabs 4 (3) — “U” Lock nuts 4(3)—M4x30 screws

Lower billet grille the hardware will be each 3pcs.

NOTE: Be Careful not to scratch the grills Surface.

- (1) Remove the factory plastic grille from your vehicle. Optional (for vehicles with black plastic cover under hood). Pop hood, remove the black plastic cover on top of factory grille(front panel) from vehicle, this will allow access to the rear of the grille shell.
- (2) Place “U” nuts on each “U” bracket tabs, the hole to hole, then billet grille into the factory grille shell. Insert the screw from front of billet grille welded tabs, the bolt go through the factory grille, then insert the tabs and nut on the bolt from , to be sure the billet grille center over the factory grille shell, then tight each nut is ok.



1



2



3

- (3) Re-install factory grille.

(We are not responsible for any scratching so please take caution during the installation.)

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!