

1979-2004 Mustang Rear Shock Tower Brace Instructions

1. Remove trunk trim pieces to expose the rear strut nuts.



2. Using a $\frac{1}{4}$ " wrench and a 15mm wrench, remove the strut retaining nut.



3. Remove the metal top and rubber bushing and install the brace.



4. Reinstall the rubber bushing and metal top, and then retighten the strut tower nut to factory spec.



5. Reinstall the trunk trim.

Please note, this is designed to be a weld in style strut bar and it is optional to do so. Please seek a local shop if welding is desired.