



Installation Instructions for 1994-2000 Ford Mustang 3.8L V6 Part # MA7338

POWER by DESIGN™

Tools Required: -10mm Socket & Ratchet -T20 Torque Head (supplied) -Flat Head Screwdriver



Parts Included: •1- MAC Mass Air Meter with Plastic Adaptor •2- Screws

1. Start by disconnecting the wire harness from the MAF sensor.

2. Next loosen the hose clamp on the stock air tube to the MAF meter. Remove the stock air tube from the MAF meter.

- 3. Remove the bolt that holds the stock air box in place and set aside for reuse.
- 4. Remove the stock air box and the MAF meter from the vehicle.

5. Remove the MAF sensor from the stock air meter and set aside for reuse with the MAC system, using the T20 torques head supplied in the kit.

- 6. Remove the four bolts that hold the stock air meter to the air box.
- 7. Install the MAC air meter the stock air box using the stock hardware.

8. Install the MAC air meter with the stock air box into the stock location and tighten in place using the stock hardware.

9. Install the MAF sensor to the MAC air meter and tighten using the hardware provided. Note: Do Not over tighten the sensor or use the stock hardware on the MAC air meter.

10. Install the stock air tube to the MAC air meter and tighten the hose clamp.

11. Reconnect the wire harness to the MAF sensor. Check to be sure that all the connections are tight.

12. You are finished!

Need to contact us?

Visit us on-line at www.macperformance.com for information on the latest products and updates for your existing products.

You can also call us at 800-367-4486, fax your request to 951-296-3044 or email tech@macperformance.com. If you experience problems with any MAC Product, please contact us immediately. A return authorization number should be requested for any merchandise being returned.

Thank you for purchasing MAC!

• MAC • 43214 Blackdeer Loop • Temecula, CA 92590 • www.macperformance.com • Local & Tech Support (951)296-3077 • US 800-367-4486 • Fax (951)296-3044 •