

CDC Side Scoops - Unpainted (94-98 All)

Item # 11017

INSTALLED ON: 1994 Ford Mustang GT

LIST OF TOOLS

Rubbing Alcohol, Adhesion Promoter, Adhesive Remover, Razor Knife, Rag

STEP 1: Make sure the temperature is over 60 degrees. Have the scoop painted. I wrapped mine in vinyl for the time being. Apply 3M tape adhesion promoter to the back lip of the scoop and allow it to dry.



STEP 2: Apply the supplied 3M tape to the back of the scoop, press it down and allow it to set for 5 minutes.



STEP 3: Clean the lip around the factory side scoop, with rubbing alcohol.



STEP 4: I applied a small amount of adhesion promoter to the lip around the scoop, this can damage the paint, so be careful if you decide to do this..



STEP 5: Peel back approximately 3" of red tape backing to expose the adhesive. Position the scoop and pull the red backing out and away from the scoop.



STEP 6: Peel the backing off, while holding the scoop still, until the entire length of red backing is removed, then press the scoop tight against the car and allow it to set.



Installation Instructions written by AmericanMuscle Customer Ryan Houck 12.16.2014