



**2005 – 2009 Mustang  
Quarter Window Closeouts  
CDC #112040**

**Note:** Read installation instructions before installation. For best results Closeouts should be installed at 70°F or warmer. If necessary, warm the area with a hair dryer or heat gun.

**Component Check List:**

<b><u>Quantity/Description</u></b>	<b><u>Part #</u></b>	<b><u>CDC</u></b>	<b><u>Installer</u></b>
1 - Driver Side Closeout	116042	<input type="checkbox"/>	<input type="checkbox"/>
1 - Pass. Side Closeout	116043	<input type="checkbox"/>	<input type="checkbox"/>
2 - Alcohol Prep	950006	<input type="checkbox"/>	<input type="checkbox"/>
1 – Instructions		<input type="checkbox"/>	<input type="checkbox"/>

**Installation Instructions**

1. Test fit parts to determine Driver and Passenger sides.
2. Clean inside of rear quarter windows with provided Alcohol Prep.
3. Peel all red backing from 3M Acrylic Foam Tape. (One side at a time)
4. Place Closeout against glass and press firmly.
5. Repeat for opposite of car.

**Thank you for choosing Classic Design Concepts for your restyling needs. If you have any questions or concerns regarding installation please contact  
[Tech@classicdesignconcepts.com](mailto:Tech@classicdesignconcepts.com) or call 866-624-7997.**