

Installation Instructions for Premium Black Leather Arm Rest Cover (05-09 All)

Installation Time: 60 Minutes

Required Tools:

Phillips Head Screwdriver



1. Flip Open the Arm Rest Lid to access the screws on the hinge. Remove the four (4) screws on the hinge with a Phillips Head Screwdriver and remove the lid from the vehicle.



2. Place the lid on a work table and remove the six (6) screws holding the plastic cover to the Arm Rest Pad.



3. Remove the plastic cover from the Arm Rest Pad.



4. Wrap the Premium Black Leather Arm Rest Cover around the Arm Rest Pad.
 - a) If the Arm Rest Cover is hard to work out of the box, wrap the cover around a book/box and sit it in the sun for 15-30 minutes to help make the cover more workable.



5. Make sure you work with the cover so stitching is lined up to your liking then reinstall the plastic cover with the six (6) screws on the Arm Rest Pad.
6. Reinstall the Arm Rest Pad with the four (4) screws onto the hinge from Step 2.

Congratulations!

You have completed installing the Premium Black Leather Arm Rest Cover on your Mustang.

Before:



After:



Installation Guide Created and Submitted by AmericanMuscle Employee, Matt Majka, on 8/23/2016