

Stainless Steel Side Scoop Insert Set (99-00 GT, 99-04 V6)

Installation time: approximately 15 minutes.

Tools needed: Flat Head Screw Drive.



Installation Instructions:

- 1) Place your flat head screw driver towards the top of the honey comb insert. Lightly pop it out of place; lifting up on the rest of the insert removing it from the car. Repeat on the other insert.



- 2) Open up the packaging containing your new inserts. Peel back the red 3M plastic backing.



- 3) Line up your new insert on top of the original insert. Firmly press down around all edges and in the center of the insert. This will make a good seal when you hear popping (air escaping from between the inserts).



- 4) Repeat steps 2 and 3 for the other insert.
- 5) Once both inserts have been applied to the stock inserts it's time to reinstall them back on to your car. Starts by placing the bottom hook into its appropriate spot.



- 6) Push the rest of the insert into the scoop. You should hear a few clicks; popping the insert in place. Repeat this on the other side of your car to complete your new installation.
- 7) Step back and admire the new look of your mustang!



Installation Instructions Written By AmericanMuscle Customer Kyle Nizlop 7.5.2013