

PART NO : ABSSSC-01 & ABSSSC-02
MUSTANG SIDE SCOOP '05-'09 & '10-'13

This Ford Mustang Side Scoops are manufactured using virgin ABS resins

Installation Instructions :-

1. Clean the mounting areas using isopropyl alcohol or equivalent
2. Peel the double side tape backing at the corners (refer to photo no. 1)
3. Place the side scoop on the correct position and peel the tape backing completely
4. Press the side scoop gently onto the car body
5. Side scoop in actual location (refer to photo no. 2)

1)



2)

