

## Modern Billet Chrome Interior Door Handle Accents (05-09 All)

**Time Required:** 15 min

**Tools Required:** None



### **Safety:**

(1) Engage Emergency Brake or insure in Park for Automatics.

### **Preparation and Install:**

(1) Thoroughly clean the door handle and remove the 3M tape.



**(2) Install the Chrome Accent by pressing firmly for 30 seconds.**



**Complete**

**Before**



**After**



**Installation Instructions written by AmericanMuscle Customer Mitch Smith 10.19.2014**