

Modern Billet Chrome Seat Tilt Lever Covers (05-14 All)

Time Necessary: Under 5 mins.

Tools Required:

- 3M double sided tape (supplied)
- Alcohol prep pad (supplied)



Required Tools

Prep:

- Ensure that the area of installation has been thoroughly cleaned before starting



Pre-installation area - clean and dust free

Installation:

1. Use the supplied alcohol prep pad to thoroughly prepare the installation area and remove any substances that will prevent proper adhesion.



2. Peel backing from the 3M double-sided tape that is already adhered to the chrome seat tilt lever cover.



3. Line up the new chrome seat tilt lever cover up with the existing plastic piece ensuring that the new chrome seat tilt lever cover is centered on top of the existing one.



4. Apply a small to moderate amount of pressure for a few seconds to ensure that the tape adheres to the plastic surface of the existing piece. Do not pull or turn for a couple of hours to allow glue to bind.



Post installation

Installation Instructions written by AmericanMuscle customer A. Lara 8.26.14