

## **Modern Billet Chrome E-Brake Handle Cover (05-09 GT, V6)**

**Time Required:** 15 min

**Tools Required:** None (Hex Key / Allen Wrench is included)



### **Safety:**

(1) Engage and Fully Extend E-Brake.

### **Preparation and Install:**

(1) Thoroughly clean the E-Brake and align the flat side of it for install.



- (2) Slide into place and tighten the two bottom set screws with the Allen Wrench.



**Complete**

**Before**

**After**



Installation Instructions written by AmericanMuscle Customer Mitch Smith 10.19.2014