

Modern Billet Chrome Mirror Control Cover (05-09 All)

Time Required: 15 min

Tools Required: None



Safety:

(1) Engage E-Brake and insure in park for Automatics.

Preparation and Install:

(1) Thoroughly clean your mirror control and remove 3M tape.



(2) Align and install.



Complete

Before

After



Installation Instructions Written by AmericanMuscle Customer Mitch Smith 10.19.2014