



Steeda Throttle Body Spacer

2005+ V6 Mustang

Instructions for Part # 555-3142

Kit contents:

- 1 Billet Throttle Body Spacers
- 1 Gasket
- 4 Bolts (M6x55)
- 4 Washers

Installation Steps

1. Remove the 4 bolts attaching the throttle body to the intake manifold.
2. Gently pull the throttle body forward and insert the gasket and spacer into the gap (re-seat the o-ring if it pulls from the groove). Loosely install one bolt to hold the pieces while lining up the other 3 bolts

The stack-up from front to rear is:

Throttle Body / Supplied Gasket / Billet Spacer / Intake Manifold.

3. Tighten the bolts to 89 in-lbs (approx. 7.5 ft-lbs).