

INSTALLATION INSTRUCTIONS

** Installation recommendation: JBA recommends in most case that the vehicle be taken to a reputable exhaust shop for installation.

40-2642

2011 Mustang 5.0 GT 3" Dual exhaust to stock H Pipe

Parts List:

Recommended Tools:

D/S Over axle pipe P/S Over axle pipe

pry bar ratchet

P/S Muffler/Tip assembly 1 15mm deep socket

D/S Muffler/Tip assembly 1 9/16 deep socket

3" Sure-Seal™ Clamp

2 channel lock pliers



Start:

- 1. Remove and inventory the JBA Exhaust System.
- 2. Disconnect the negative battery cable and allow the exhaust system to completely cool.
- 3. Loosen the clamps attaching the exhaust to the stock H Pipe assembly. Slide the clamp back to separate the two.



4. Loosen the clamp connecting the exhaust pipe to the muffler. Wiggle the exhaust pipe free from the muffler. Remove the exhaust pipe from car. You may have to jack the car up by the frame to get the pipes out from over the axle.



7. Install the new over axle pipes.

Slide the original clamps over the

clamps onto each pipe, then insert

pipe to hold in place but do not

tighten. Slip the 3" Sure Seal™

into muffler/tip assemblies .



9. With the axle pipes in the muffler assemblies adjust mufflers to be flat, and the tips an equal distance from the bumper cover, Then tighten all clamps securely.



- 10. Using a soft cloth, wipe the new JBA tips clean.
- 11. Reconnect the battery and start the vehicle to check for leaks.

NOTES:

1.) All exhaust systems expand about 1" rearward whent exhaust temperature rises.

To get more power out of your Mustang, JBA offers long tube headersheaders and high flow h-pipes for the 5.0L. For more information about these and other quality performance products from JBA visit us online at www.jbaheaders.com





Sutton High Performance - 2005 Mustang 4.6L - Vortech supercharger Horsepower - 665rwhp • 1/4 Mile - 9.82 @ 136 mph





Vortech Superchargers - 2005 Mustang 4.6L 3v Horsepower - 575 • Top speed - 192 mph



- the rubber hanger from the hanger rod at inside, front of muffler (a little lube helps). Slide the muffler assembly forward and remove from slip hangers.
- 6. Slide the JBA muffler/tip assemblies hangers into the rubber isolators on each side. WD40 or similar will make this easier.

