

## How to install Black Lower Rear Valance Decal (99-04 GT, V6, Mach 1)

**Time:** 15 minutes

**Tools:**

- ✓ Squeegee (included with Valance)
- ✓ Spray bottle with distilled water and soap mix

**Note:** This install was completed on a 2000 Mustang V6

**Prep Work:** Clean rear valance area thoroughly and make sure its dry, its best to complete the install in a cool clean place away from the sun.

1. Spray the Valance generously with soap and water mix ensuring that the area to be covered has soap and water all over it.



2. Remove the Valance cover from the 3M paper and spray the sticky side generously with the soap and water mix.



3. Prior to attaching the Valance cover spray the Valance area again and attach the Valance cover in place. The soap and water mix will allow you to position the Valance cover to the exact spot you want it.



4. Once in place use the squeegee to smooth out the Valance cover removing the excess soap and water mixture and removing any air bubbles.



5. Return to the Valance after a few minutes and use the squeegee as needed to smooth out the Valance removing any additional air bubbles.



Let it dry for 24 hours then wipe it down with some quick detailer and go!



Installation instructions written AmericanMuscle customer by Roscoe Lewis order 7.01.2014