

Installation Instructions for 2005+ Mustang Strut Bar

Tools Required:

3/8" Drive Ratchet and 13mm Socket or 13mm Wrench

Step 1:

Remove eight strut mount nuts as shown below with a 13mm socket or wrench.



Step 2:

Place strut bar over strut mount studs and re-install 13mm nuts removed in Step 1.

